

Supply of Vehicle spareparts Comparative statement for FY 2023-2024

SL.No	Description of Item (2)	Unit	Qty.	Land Cruiser (Ambulance)	Hilux (Bankok)	Mitsubishi Pajero	DCM Eicher	Tractor (Farmtrac)	School Bus - Eicher	Maruti Van	Mahindra Bolero	Dumper (Refuse Collector)	Cesspool
1	AC radiator fan	no.	1				850	900	850	700	800		
2	Air cleaner hose pipe	no.	1							380	450		
3	Air conditioner filter	no.	1				2650		2650	450	500		
4	Air filter element	no.	1				2650		2650	450	500		
5	Alternator bearing	no.	1	1800	1750		550	450	550	450	500		
6	Alternator carbon bush	set	1	2500	2400		1500		1500	900	1200		
7	Alternator rectifier	no.	1				1000		1000	1100	1950		
8	Apron sub assy RHLH	no.	1										
9	Arm sub assy front suspension LWR RH	no.	1							800	3500		
10	Armature assy starter	no.	1				4000		4000	1800	3800		
11	Axle oil seal rearfront	no.	1	1800	2300		650		650	350	450		
12	B FUEL SYSTEM, Cam plate	no.	1										
13	Back light assy rear RHLH	no.	1	18500	25000	28000	800		800	650	750		850
14	Back light bulb double point	no.	1	100	100	100	100	100	100	100	100	100	100
15	Back light bulb single point	no.	1	100	100	100	100	100	100	100	100	100	100
16	Balance front bumper	no.	1										
17	Battery terminal end	no.	1	200	200	200	200	200	200	200	200	200	200
18	seventy	no.	1	11000	11000	11000	10000	14000	10000	5000	9000	10000	15500
19	Bearing cam shaft	set	1										
20	Bearing connecting rod	no.	1				3000		3000	1000	3000		
21	Bearing crank shaft	set	1				2800		2800	900	2900		
22	Bearing differential inner	no.	1				2850		2850	850	1950		
23	Bearing differential side gear	no.	1				3800		3800	8000	4600		
24	Bearing front wheel inner	no.	1	8500	9000		4500		4500	850	1800		

25	Bearing front wheel outer	no.	1	8500	9000		4500		4500	850	1800		
26	pump	no.	1										
27	Bearing rear axlewheel	no.	1	7000	7000		3900		3900	590	2500		
28	frontouter	no.	1										
29	Bearing self starter front	no.	1										
30	Bearing self starter rear	no.	1										
31	Belt V compressor and collar	no.	1				2300		2300				2500
32	Bendex pinion starter	no.	1				3000		3000	2100	2500		
33	pump	no.	1										
34	Blade vacuum pump	no.	1										
35	Body balance rod assy	no.	1										
36	Body balance rod bracket	no.	1										
37	Body hoodpacking	no.	1										
38	Body mounting	no.	1										
39	per mtr	no.	1										
40	Bonet mountinghood	no.	1										
41	Bonet stopper lock	no.	1										
42	Brake bleeder screw	no.	1										
43	Brake booster assy	set	1										
44	Brake booster kit	set	1										
45	Brake disc assy front	no.	1							3000	3900		
46	Brake line pipe	no.	1				850		850	450	650		
47	Brake master cyl. Assy	set	1							5500	6500		
48	Brake shoe	set	1				1950		1950	2000	1900		
49	Bumper bracket	no.	1										
50	Bumper front assy.	no.	1							3500	7500		
51	Bumper lock	no.	1							2850	5000		
52	Cable speedometer	no.	1	4500	5000		1800		1800	900	1250		
53	Cap assy brake master cyl.	set	1							3500	6000		
54	Cap assy fuel filter	no.	1				650		650	450	850		
55	Ceeling roof per mtr	no.	1										
56	Center bearing assy	no.	1				4500		4500		3500		5800
57	Center bolt and nut	set	1	300	350		450		450	250	300		550

58	Clutch master assy	no.	1				3500		3500	2800	4000		
59	Clutch master assy cap	no.	1				1800		1800	950	2500		
60	Clutch master cy assy	set	1				3500		3500	2800	4000		
61	Clutch master cyl.kit	set	1				1850		1850	850	1650		
62	clutchbrake pedal bracket	no.	1							6500			
63	Coil spring front each	no.	1							1000	2500		
64	Counter gear assy	no.	1				9000		9000	5500	8500		
65	Counter gear front brg	no.	1										
66	Crank shaft	no.	1				31000		31000	9000	19000		
67	Crank shaft oil seal	no.	1				850		850	750	850		
68	Crank shaft timing pulley	no.	1										
69	Crown and tail final gear kit	set	1				35000		35000	10000	27000		
70	Lh	no.	1	30000		28000					18000		
71	Rh	no.	1	30000		28000					18000		
72	CV joint assy. LH	set	1	30000		28000					18000		
73	CV joint assy. RH	set	1	30000		28000					18000		
74	Cyl. Wheel rear kit	set	1							950	1250		
75	Cylinder head gasket	no.	1				3500		3500	1850	2500		
76	Darkling Rod Front	no.	1				8500		8500				
77	Distributive head plug	no.	1							1850			
78	Door lock and key front RHLH	no.	1				6500		6500	4500	8500		
79	Draglink assy	no.	1				9500						
80	Draglink kit	set	1				2500		2500				
81	Engine block assy	no.	1							29000			
82	Engine linner set	set	1				8500		8500	6500	7500		
83	Engine mounting front	no.	1				950		950	750	850		
84	Engine mounting rear	no.	1				950		950	750	850		
85	assy front suspension LWR LH	no.	1							1250	3500		
86	Fan belt	no.	1	3500	3500		1900		1400	1000	1800		
87	Fan sub assy	no.	1				2500		2500	850	1500		
88	Fender RHLH	no.	1							4500	7500		
89	FIP fuel pipe with washer	set	1								1200		
90	First gear	no.	1							3500	6500		

91	Flasher indicator	no.	1				2500		2500	1800	2000		
92	Fly wheel bearing	set	1				950		950	650	1200		
93	Fly wheel bearing	no.	1										
94	Fog light assy	no.	1				1300		1300	1300	1300		
95	forth gear	no.	1							3800	8500		
96	four wheel cross bearing	no.	1								1800		
97	Front axle oil seal inner	no.	1				650		650	450	500		
98	Front axle oil seal outer	no.	1				650		650	350	550		
99	Front stabilizer bar	no.	1								2500		
100	Front stabilizer bar bush	no.	1							550	850		
101	Front wheel check nut	no.	1				750		750	350	450		
102	Front wheel check nut lock	no.	1				350		350	250	300		
103	Front wheel checknut washer	no.	1				200		200	150	200		
104	Fuel filter	no.	1	3500	2500		1200		1200	750	600		
105	Fuel tank assy	no.	1							4500	6500		
106	Fuel tank filler cap	no.	1				650		650	550	750		
107	Fuel tank inlet pipe	no.	1				1250		1250	1000	1350		
108	Fuse Eighty A	no.	1	50	50	50	50	50	50	50	50	50	50
109	Fuse fifteen A	no.	1	50	50	50	50	50	50	50	50	50	50
110	Fuse seven point five A	no.	1	50	50	50	50	50	50	50	50	50	50
111	Fuse Ten A	no.	1	50	50	50	50	50	50	50	50	50	50
112	Fuse twenty A	no.	1	50	50	50	50	50	50	50	50	50	50
113	Gasket engine overhaul	st	1				15000		15000	6000	13000		
114	Gear lever bush	no.	1				850		850	550			
115	Gear lever control kit	set	1				850		850	550			
116	Gear synchronizer ring	no.	1				1350		1350	850	1200		
117	Gear thrust washer	no.	1				850		850	850	750		
118	assy	no.	1				20000		20000	7500	9500		
119	Hand brake cable F	no.	1							850	950		
120	Hand brake cable R	no.	1							850	950		
121	Handle for window door	no.	1				650		650	550	650		
122	Handle front door inner RHLH	no.	1				650		650	350	450		
123	RHLH	no.	1				550		550	250	450		

124	Handle rear door outer RHLH	no.	1							250	450		
125	Head and rotor assy	set	1							16000			
126	Head lamp assy RHLH	no.	1							2000	3500		
127	Head lamp bulb	no.	1	450	450	450	450	450	450	450	450	450	450
128	Helper spring leaf	no.	1				2500		2500				3500
129	Hood lock assy	no.	1										
130	Horn st.	set	1	3000	2500	2500	2500		2500	1700	2000	2500	2500
131	Hose pipe clamp	no.	1	150	150	150	150	150	150	150	150	150	150
132	Hose radiator Lower outlet	no.	1				450		450	350	450		
133	Hose radiator Upper inlet	no.	1				550		550	400	500		
134	RHLH	no.	1				3500		3500	650	850		
135	Indicator side light bulb	no.	1	50	50	50	50	50	50	50	50	50	50
136	Inner oil seal rear wheel	no.	1				850		850	750	850		
137	Kingpin bearing	no.	1				1250		1250				
138	Kingpin bush	no.	1				450		450				
139	KM cable	no.	1	3000	3000		1200		1200	850	1000		
140	Knuckle hub front RhLh	no.	1							4500	5500		
141	Knuckle oil seal st.	set	1				850		850	750	850		
142	Mirror LH	no.	1				550		555	450	500		550
143	Mirror RH	no.	1				550		550	450	500		550
144	Nutbolt door lock key	no.	1	100	100	100	100	100	100	100	100	100	100
145	Oil filler	no.	1	3500	2500		550		550	300	650		
146	Oil seal rear axle inner	no.	1				850		850	750	850		
147	manual strg	no.	1							850	1700		
148	Oil seal steering worm gear	no.	1							850	1700		
149	Oil seal timing gear case	no.	1							650	850		
150	Pati clamp	no.	1	200	200	200	200	200	200	200	200	200	200
151	Pilot bearing clutch	no.	1				1850		1850	650	1000		
152	Piston ring	set	1				9000		9000	3500	7500		
153	Piston with pin	set	1				12000		12000	6500	9000		
154	Power steering tank	no.	1				1200		1200		1000		
155	Propeller shaft assy f	no.	1							6500			
156	Propeller shaft assy r	no.	1							6500			

157	Propeller shaft bearing	no.	1							1800			
158	Propeller shaft yoke	no.	1								2500		
159	Pushing clip	no.	1	50	50	50	50	50	50	50	50	50	50
160	RHLH	no.	1										
161	Radiator assy	no.	1				28000		28000	6500	9000		
162	Radiator cap	no.	1				350		350	250	400		
163	Rain guard	no.	1				1000		1000	1650	2800		
164	Rear axle cone	no.	1							450	650		
165	Rear axle shaft Lh	no.	1				12000		12000	8000	11000		
166	Rear axle shaft Rh	no.	1				12000		12000	8000	11000		
167	Rear dekey shock absorber	no.	1							950			
168	Rear view mirror	no.	1				550		550	650	750		
169	Rear wheel Cyl. RHLH	set	1							850	1500		
170	Rear wheel Cyl. RHLH	set	1							850	1500		
171	RHLH	no.	1								1950		
172	Relay head lamp	no.	1	650	650		500	500	500	500	500	500	500
173	Relay starter	no.	1	1200	1200		500	500	500	500	500	500	500
174	Reverse gear	no.	1				8500		8500	3500	6500		
175	Roller bearing for counter gear	no.	1				2800		2800	690	1650		
176	Second gear	no.	1				3500		3500	4500	5500		
177	Self starter assy.	no.	1				18000		18000	9500	16500		
178	Self starter bearing	no.	1				850		850	650	750		
179	Self starter carbon bush	set	1				1850		1850	1200	1650		
180	Self starter solenoid switch	no.	1				2500		2500	1850	2850		
181	Shim	no.	1	80	80	80	80	80	80	80	80	80	80
182	RF	no.	1				120		120	650	950		
183	Shock absorber metal bush	no.	1				250		250		1000		
184	Shock absorber retainer washer	no.	1	100	100	100	100	100	100	100	100	100	100
185	Shockabsorber front each	no.	1				2500		2500	4500	5500		
186	Shockabsorber rear each	no.	1				2500		2500	2850	3000		
187	Speedor cable	no.	1				1900		1900	850	1500		
188	brg	no.	1	3500	3000		2800		2800	1200	1850		
189	Spindle hub front assy.	no.	1							3600	4800		

190	Spiral Cable	no.	1										
191	Spring bumper	no.	1						450	650			
192	Spring clip	no.	1	450	450		550		550	350	450		
193	Spring front main or first leaf	no.	1				2800		2800		1800		
194	Spring front main or fourth leaf	no.	1				2500		2500		1650		
195	leaf	no.	1				2750		2750		1750		
196	Spring front main or third leaf	no.	1				2700		2700		1700		
197	Spring hanger pin	no.	1				450		450		350		
198	Spring metal bushing	no.	1				400		400	300	350		
199	Spring rear fifth leaf	no.	1	2800	2700		3000		3000	2000	2100		
200	Spring rear fourth leaf	no.	1	2650	2600		2900		2900	2100	2200		
201	Spring rear main leaf	no.	1	4500	4250		3500		3500	2500	2500		
202	Spring rear second leaf	no.	1	4200	4000		3300		3300	2250	2250		
203	Spring rear seventh leaf	no.	1	2400	2350		2800		2800		2000		
204	Spring rear sixth leaf	no.	1	2750	2700		3700		3700		2000		
205	Spring rear third leaf	no.	1	400	3900		3000		3000	2000	2150		
206	Spring rubber bushing	no.	1	250	250		650		650	450	500		
207	Spring shackle pin	no.	1	450	450		400		400	350	400		
208	Spring shackle plate	no.	1	1850	1900					990	1300		
209	Spring torsion bar	no.	1										
210	Spring u bolt	no.	1	650	650		750		750	450	500		
211	Stabilizer bush D type	no.	1	850	950						400		
212	Starter armature assy	no.	1				6500		6500	4500	5000		
213	Starter assy	no.	1				18000		18000	9500	16500		
214	Steering box bearing	no.	1							9500	15000		
215	Steering corsssector shaft	no.	1				2500		2500	1900	2000		
216	Steering cover	no.	1	850	950	950	1000		1000	650	850		
217	Steering rack assy.	no.	1								24000		
218	Steering rack end RhLh	no.	1								1950		
219	Steering worm gear oil seal	no.	1							850	1950		
220	Suspension arm bush	no.	1								1500		
221	Switch oil pressure sender	no.	1							650	850		
222	Switch water temperature	no.	1							750	950		

[illegible]